
























Assemble Instruction

18840003-01 1123035 1152004 1164491 1186499		
A		5
B		1
C		1
D		1
E		1
F		2
G		1
H		1
I		1
J		1
K	 ϕ 8x25mm	16
L	 ϕ 5x8mm	7
M		1
N		1
O		1





LOCK

please lock the pallet when using the
angelad just machine.