



- | | |
|---------------------------------------|-----------------------------------|
| D Montageanleitung | GB Assembly instructions |
| FR Notice de montage | IT Istruzioni di montaggio |
| NL Handleiding voor de montage | PL Instrukcja montażu |
| CZ Montážní návod | SK Návod na montáž |
| HU Szerelési útmutató | RO Instrucțiuni de montaj |
| TR Montaj talimati | RU ИНСТРУКЦИЯ ПО МОНТАЖУ |

3822.90 Teddy 1
3823.77 Teddy 2













**Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба**

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • İsim • Название

Nr. • No. • N° • Номер • Č • Sz

Typ • Type • Típus • Típus • Tipo
Тип





① x1



② x1

③ x1



A



Achtung:
Bitte Schraube A vorsichtig von Hand eindrehen.
Bitte keinen Akkuschauber benutzen.
Please screw in part A by hand.
Please do not us a cordless drill.



B



Achtung:
Bitte Schraube A vorsichtig von Hand eindrehen.
Bitte keinen Akkuschauber benutzen.
Please screw in part A by hand.
Please do not us a cordless drill.

