


























# Assemble Instruction

1205403			1		2		3	
A		5	4		5		6	
B		1						
C		1						
D		1						
E		1						
F		2						
G		1						
H		1						
I		1						
J		1						
K		16						
L		6						
M		4						
N		1						
O		1						
P		1						
Q		1	7		8			





**LOCK**

please lock the pallet when using the  
angelad just machine.